

When a track mounted blind greater than 5' in width is being installed, the following instructions must be adhered to:

Heavy Duty Systems

On a Heavy Duty System, the brackets are permitted to hang down from the bottom track. The set screws need to be removed from the brackets. The track needs to be drilled (9/64 bit) for our F022 screws to be inserted.

Light Duty Systems

On a Light Duty System, the brackets must be installed on the face of the header or track. The set screws need to be removed from the brackets. The track needs to be drilled (9/64 bit) for our F022 screws to be inserted.

